

Part No.	Description	No. Req'd
DE43	Front Bearing Housing	1
DE44	Bearing	1
DE45	Front Ball Bearing Retainer	1
DE46	Screw	4
DE47	Screw	3
DE48	Washer	9
DE49	Nut	3
DE50	Crank	1
DE51	Stud, upper	2
DE52	Stud, Lower Mounting	1
DE53	Stud, Lower Mounting	1
DE54	Guide Adjustment Nut	3
DE55	Shaft for Ball Bearing	1
DE56	Seated Crank Ball Bearing	1
DE57	Lock Nut for Shaft	1
DE58	Crank Ball Bearing Lock Nut	1
DE59	Connecting Rod	1
DE60	Screw	2
DE61	H. Guide	1
DE62	Cross Head	1
DE63	Wrist Pin	1
DE64	Wrist Pin Felt Pad	1
DE65	Connecting Rod Washer	1
DE66	Screw	1
DE67	Guide Washer	1
DE68	Screw	6
DE69	Knife Lock Washer	1
DE70	Screw	1
DE71	Screw	2
DE72	Handle Bracket	1
DE73	Screw	1
DE74	Screw for Handle Bracket	1
DE75	Operating Handle Lock Nut	1
DE76	Operating Handle	1
DE77	Switch	1
DE78	Switch Base	1
DE79	Screw	3
DE80	Oiling device	1
DE81	Oil Tube	1
DE82	Eyelet	1
DE83	Cover for Oil Tube	1
DE84	Long Wicking	3
DE85	Screw	4
DE86	Screw	2
DE87	Circle	2

