

Part No.	Description	No. Req'd
DE160	Shaft for Grank	1
DE161	Idle Gear	1
DE162	Gear and Shaft	1
DE163	Bell Crank	1
DE164	Ball Bearing for Grank	2
DE165	Spacer for Bell Bearings	1
DE166	Retaining Ring for Bell Crank	1
DE167	Drive Pulley with Driver	1
DE168	Bearing for Bell Crank	1
DE169	Washer for Shaft	1
DE170	Retaining Ring for Shaft	1
DE171	Pin for Bell Crank	1
DE172	Bearing for Drive Shaft	1
DE173	Thrust washer 15	2
DE174	Spiral Gear 15	1
DE175	Bearing for Drive Shaft	1
DE176	Bearing for Drive Shaft	1
DE177	Key	1
DE178	Driver shaft with Gear	1
DE179	Lock Nut for Shaft	1
DE180	Pin for Sharpener Housing	1
DE181	Spring for Bell Crank	1
DE182	Bearing for Gears 20	2
DE183	Spur Gear 20	2
DE184	Thrust Washer for Bottom Plate	2
DE185	Push Rod	1
DE186	Roll for Push Rod	1
DE187	Bearing for Screw Shaft	1
DE188	Bottom Plate	1
DE189	Oil Pad and Holder	1
DE190	Spreader Pin	1
DE191	Screw	1
DE192	Screw	3
DE193	Screw	2
DE194	Rivet	4
DE195	H.Oil Pad	1

